



Boat Lifts

IMM/QUALITY BOAT LIFTS
17030 ALICO CENTER ROAD
FORT MYERS, FLORIDA 33967
TEL: 239/432-9110 FAX: 239/432-0019
TOLL FREE: 800/545-5603



Boat House Lifts



Lift Hanger Bearings are the most common and effective way to mount a lift inside of a new or existing boat house. The bearings are fastened to the hanger assembly which then slides over the stringer bands of the boat house. Once in place, the brackets are fastened to the bands using Stainless Steel bolts and requires no drilling of the bands.




Stringer Brackets are a roof riser which is mounted directly on top of a beamed boat lift and connects the outer support bands to the lift. These brackets are used to support the roofing system.




Lift Capacities

4,500 lbs.
7,000 lbs.
10,000 lbs.
13,000 lbs.
16,000 lbs.
20,000 lbs.
27,000 lbs.



Suspension Brackets allow you to hang a standard 4-post lift in various positions along overhead support beams and gives full adjustability in all directions.

- Available in capacities ranging from 4,500 lbs. -27,000 lbs.
- Available with Belt, Chain, or Direct Gear drives
- Various mounting options
- Pre-assembled and ready to install
- Utilizes the full strength of the roof band
- Custom configurations available for any application



Suspension Bracket

Side Mount Bracket

Hanger Bearings

For Our Nearest Dealer, Call Toll Free : **(800) 669-3515**

To Learn More About Our Products, Please Visit Us On The Web @ www.immboatlifts.com OR www.qualityboatlifts.com